

SOLO-KP 200 – QUICK START GUIDE

Please use web server on: www.easysset.eu


Thank you for purchasing our device.



1. Read this Quick Start Guide first...
2. Install power supply wiring from PS source to location.
3. If antenna is not already mounted on the housing, mount antenna on a location away from speaker.
4. **IMPORTANT: USE A MICRO SIM CARD (Micro-SIM) WITH MEMORY FOR UP TO 250 CONTACTS!**
Insert SIM card to be used for SOLO-KP device in your personal mobile phone to erase PIN code.
5. **IMPORTANT: ERASE THE PIN CODE ON SIM CARD!**
6. Insert SIM card in SOLO device – gold contacts down and cut off corner RHS.
The unit must be switched OFF when you insert the SIM!
Insert SIM carefully as SIM holder is fragile if forced!
7. Connect outputs and power cable to SOLO-KP device.
8. Connect SOLO-KP device to source power supply voltage.
9. Wait until YELLOW LED start flashing in 5 second interval (0,5 sec ON / 5 sec OFF) and BLUE LED (LED 1) starts flashing. This is set in around 30 seconds.
10. SOLO-KP unit is now ready to operate.
IMPORTANT: Before sending any SMS commands, the device must be in normal operation mode!

WIRING

Wiring is minimal. Apart from Power supply to SOLO & door release wires, there is no other required wiring.



***Do not use the Power out (12V AUX) for electric lock driving!**
You can use it to power external sensors: Short-term current load (up to 1 minute) - up to 500mA; Long-term current load - up to 100mA! Use separate power source for door electric lock!

PROGRAMMING SETTINGS BY SMS (TEXT)

Note: You can send individual commands like: ;PIN1=1234; or together in one long text message. **Don't exceed 160 characters.**

For each keypad entry SOLO-KP incorporates a group of parameters. SOLO-KP supports up to 200 call groups (apartments).

SET A GROUP OF PARAMETERS FOR THE APARTMENTS –

KPAx for telephone number 1, **KPBx** for telephone number 2 and **KPOx** for defining which Output relay to trigger: (default is set for Output 1):

;KPA1=telnum1;KPB1=num2;KPO1=1; - for 1st apartment
;KPA2=telnum1;KPB2=num2;KPO2=1; - for 2nd apartment, to 200
;KPA200=telnum1;KPB200=num2;KPO200=1; - for 200th apart.

USING THE KEYPAD FOR CALLING THE APARTMENTS:

Type apartment number on the keypad and press '#' to confirm:
Ex.: 1# for calling the 1st apartment or 15# for calling apart. no. 15.

SETUP ACCESS CODES (PIN1 to PIN2000) – FOR DIRECT ACCESS:

NOTE: PIN1 to PIN1000 for Relay 1, PIN 1001 to PIN2000 for Relay 2.

Set 4 digit PIN access codes by sending SMS to SOLO-KP:
;PIN1=1234;PIN2=2345;...;PIN2000=5588; (first digit ≥ 1)

Delete PIN access codes by sending:
;PIN1=;PIN2=;PIN3=;PIN4=;PIN5=; ... up to ;PIN2000=;

Check current PIN access codes: Request all PIN codes: ;PPIN;
Request a block of PIN codes: ;PPIN=1,5; (access codes 1 – 5)

SETUP TEMPORARY SPIN ACCESS CODES (SPIN1 to SPIN100):

Up to 100 SPIN Access Codes and how many of times will it be used.

NOTE: Set the SPIN codes active output first: ;SPINO=1; and SPIN code and how many times will it be used: ;SPIN8=4321;SPINC8=3;
Explanation: Output set to trigger is Relay 1, SPIN8 code 4321 can be used 3 times and after the 3th time won't be valid anymore.

Check current SPIN access codes: ;PSPIN; - prints SPIN parameters.

USING THE PIN ACCESS CODES FOR DIRECT ENTERING:

Type PIN access code on the keypad and press '#' to confirm:
Ex.: 1234# (1 long beep = PIN correct, 3 short beeps = PIN incorrect)

SET AUTHORISED CALLER ID (CLIP) USERS (In total up to 500):

All KPax and KPBx numbers are used as intercom and as Caller ID numbers (400). You could use additional 100 Caller ID numbers.
;+CLP1=07798765432;CLP2=xxxxxxxxxx;...up to CLP100;

CHANGE SPEAKER LEVEL (default is 10 max is 20): ;+SPK=12;

CHANGE MICROPHONE LEVEL (default is 15 max is 40): ;+MIC=20;

SET OUTPUT SWITCHING CONFIGURATION:

Output 1 (3 second pulse default = ;OS1=3;). Change to 5 second pulse ;OS1=5;. Output 2: Change to 5 second pulse ;OS2=5;.

NOTE: If the confirmation SMS is needed, put "+" at the beginning of the SMS command: ;+KPA1=xxxxxxxxxx;KPA2=xxxxxxxxxx;

OPERATION & TESTING

Follow these steps to test the system...

1. SWITCH ON THE POWER: The device will beep once every 10 sec. as it searches for the network. When it connects you will hear 3 quick beeps. BLUE LED starts flashing (2 – 5 are recommended).

2. PROGRAM BY SMS: Send minimum setting ;+KPA1=07798765432; (using your own phone number).

3. REPLY CONFIRMATION: You should receive an SMS back to confirm the setting. If you don't, you either left off the '+' in the SMS string, or the device is not ready, or the SIM has no credit.

4. PRESS BUTTON 1 on the keypad and press '#' to confirm: The device initiates the call: you hear beeps to start dialing and then a ringtone (which can be muted: ;+MUT=1;).

5. OPEN THE DOOR: Press 11 on your telephone when the intercom call is established and Output Relay 1 will switch (21 for Relay 2).

SWITCHING RELAY OUTPUTS: 3 ways to switch the outputs:

1. DURING AN INTERCOM CALL (DTMF): Press 11 for Output 1 'ON' & 10 for Output 1 'OFF' (if set to latching) and 21 for Output 2 'ON' & 20 for Output 2 'OFF' (latching only).

2. BY SMS: Send: ;ORC1=1; for Output 1 'ON' and ;ORC2=1; for Output 2 'ON'.

3. BY CALLER ID (dial in): Call the SOLO-KP device from one of the programmed telephone numbers. All KPax and KPBx numbers are at the same time used as intercom numbers and as Caller ID numbers. Example: The users under parameters KPA1 and KPB1 can call SOLO device and activate the output defined by the KPO1 parameter.

EASYSSET PROGRAMMING SOFTWARE

Test the unit before trying to use programming software!

1. Get the software EasySet & USB driver files from the CD or WEB.

2. Install the EasySet software (please be careful to download the correct PC program - x86 or x64): Double click on *.msi file.

3. Plug device into your PC with USB to Mini USB cable: With valid SIM card and in normal operation mode – the SOLO device must be registered on the GSM network, BLUE LED: 2 – 5 flashes.

4. Start EasySet SW: Double click on EasySet icon. The SOLO must be connected to PC via USB. Select connection port: choose the COM port number (Device manager → Ports) and click Connect.

5. Program settings: Always "Read configuration" first, before any programming action by PC. Go through the tabs to change settings. From the 'Home' tab press "Send configuration" to program the SOLO. Then "Save configuration to file" for future access via "Load configuration from file".

TROUBLESHOOTING

Please check the following before calling for support:

1. Will not connect: Change network, move antenna or check if connected properly, try before installing: BLUE LED should flash 2 – 5 times.

2. Audio interference on the phone: Move antenna to new location, improve signal, don't put antenna near speaker.

3. Will not call: Set User number/s to call (KPA1-KPA100 and KPB1-KPB100) or check SIM card is working in a phone first.

4. Gate release doesn't work: Check connections on gate control side.

TECHNICAL SUPPORT

See the complete Installation Manual for full information. This is a basic "Quick Start Guide" only. Please contact your Supplier for further information, if you have tried the above and cannot resolve the issue.

Web Server: www.easysset.eu

Our Android apps EasySet you can install free of charge from Google Play:



<https://play.google.com/store/apps/details?id=com.marscommerce.esweb>



<https://play.google.com/store/apps/details?id=com.marscommerce.easycontrol>

Our IOS apps EISWARE you can install free of charge from Apple Store:



<https://itunes.apple.com/app/eisware-web/id1137960053?mt=8>



<https://itunes.apple.com/us/app/eisware-control/id1220908841?mt=8>